Instructions for Removing and Replacing Puchacz Trailer Cover

NB: Minimum of three people required

To remove the cover:

1. Release all bungees
2. Stand on the right hand (starboard) side of the trailer and take hold of the cover above the central ridge pole
3. Carefully slide the cover off the trailer
4. Lay the cover on the ground alongside the trailer and fold it once lengthwise, eyelets facing inwards
5. Take each end to the centre
6. Repeat folding until you have a manageable package
7. Store the cover on a clean surface
8. Remove both ridge poles and store them safely

To replace the cover:

1. Place the shortest ridge pole at the rear end of the trailer, rearmost legs in the locating slots cut in the floor runner
2. Locate the longest ridge pole centrally in the trailer and onto the spigot on the short ridge pole
3. Place the cover on the ground on the right hand (starboard) side of the trailer, eyelets facing inwards
4. Unfold the cover
5. Take hold of the cover along the folded edge and drape it over the ridge pole
6. Carefully centralise the cover longitudinally, then laterally
7. Hook on the bungees

NB: Flap at front end has a separate bungee.